



1801 W. ST CHARLES RD  
MAYWOOD, IL 60153  
(708) 345 2075

## INSTALLATION INSTRUCTIONS FOR SWB-6-LR BOXES

### INSTALLATION INSTRUCTIONS ON PRE-FINISHED FLOOR

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Nail box to sub floor using outside tabs
- 4) Finished floor should be brought up to edges of box on the 3" sides and within 1/4" of the threaded inner "ears" creating a "shelf" to accommodate the larger tabs on the adjusting ring

**\*\*\*IMPORTANT\*\*\* FINISHED FLOOR MUST COVER OUTSIDE TABS OF BOX BY AT LEAST 1/4"**

- 5) Drop adjusting ring into opening of finished floor and align inner "ears" (outside tabs should rest on finished flooring)
- 6) Mount provided receptacle to adapter plate. Add gasket. Drop into aligned adjusting ring.
- 7) Place outside gasket around entire assembly
- 8) Place brass plate on top of gasket, making sure all inner ears are aligned
- 9) Secure brass plate and adjusting ring to inner threaded ears of box using (6) 6/32 x 3/4" or 1-1/4" brass screws (all included)

### INSTALLATION INSTRUCTIONS ON FINISHED FLOORS

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Use box as a template for routing by turning it over onto wood floor and tracing outside nailing tabs onto floor
- 4) Routing depth should be between 1/4" and 1/2"
- 5) Make sure inside "ears" are free of any flooring underneath to allow for brass assembly screw
- 6) Follow above steps 5 through 9



1801 W. ST CHARLES RD  
MAYWOOD, IL 60153  
(708) 345 2075

## INSTALLATION INSTRUCTIONS FOR SWB-6-LR BOXES

### INSTALLATION INSTRUCTIONS ON PRE-FINISHED FLOOR

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Nail box to sub floor using outside tabs
- 4) Finished floor should be brought up to edges of box on the 3" sides and within 1/4" of the threaded inner "ears" creating a "shelf" to accommodate the larger tabs on the adjusting ring

**\*\*\*IMPORTANT\*\*\* FINISHED FLOOR MUST COVER OUTSIDE TABS OF BOX BY AT LEAST 1/4"**

- 5) Drop adjusting ring into opening of finished floor and align inner "ears" (outside tabs should rest on finished flooring)
- 6) Mount provided receptacle to adapter plate. Add gasket. Drop into aligned adjusting ring.
- 7) Place outside gasket around entire assembly
- 8) Place brass plate on top of gasket, making sure all inner ears are aligned
- 9) Secure brass plate and adjusting ring to inner threaded ears of box using (6) 6/32 x 3/4" or 1-1/4" brass screws (all included)

### INSTALLATION INSTRUCTIONS ON FINISHED FLOORS

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Use box as a template for routing by turning it over onto wood floor and tracing outside nailing tabs onto floor
- 4) Routing depth should be between 1/4" and 1/2"
- 5) Make sure inside "ears" are free of any flooring underneath to allow for brass assembly screw
- 6) Follow above steps 5 through 9



1801 W. ST CHARLES RD  
MAYWOOD, IL 60153  
(708) 345 2075

## INSTALLATION INSTRUCTIONS FOR SWB-6-LR BOXES

### INSTALLATION INSTRUCTIONS ON PRE-FINISHED FLOOR

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Nail box to sub floor using outside tabs
- 4) Finished floor should be brought up to edges of box on the 3" sides and within 1/4" of the threaded inner "ears" creating a "shelf" to accommodate the larger tabs on the adjusting ring

**\*\*\*IMPORTANT\*\*\* FINISHED FLOOR MUST COVER OUTSIDE TABS OF BOX BY AT LEAST 1/4"**

- 5) Drop adjusting ring into opening of finished floor and align inner "ears" (outside tabs should rest on finished flooring)
- 6) Mount provided receptacle to adapter plate. Add gasket. Drop into aligned adjusting ring.
- 7) Place outside gasket around entire assembly
- 8) Place brass plate on top of gasket, making sure all inner ears are aligned
- 9) Secure brass plate and adjusting ring to inner threaded ears of box using (6) 6/32 x 3/4" or 1-1/4" brass screws (all included)

### INSTALLATION INSTRUCTIONS ON FINISHED FLOORS

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Use box as a template for routing by turning it over onto wood floor and tracing outside nailing tabs onto floor
- 4) Routing depth should be between 1/4" and 1/2"
- 5) Make sure inside "ears" are free of any flooring underneath to allow for brass assembly screw
- 6) Follow above steps 5 through 9



1801 W. ST CHARLES RD  
MAYWOOD, IL 60153  
(708) 345 2075

## INSTALLATION INSTRUCTIONS FOR SWB-6-LR BOXES

### INSTALLATION INSTRUCTIONS ON PRE-FINISHED FLOOR

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Nail box to sub floor using outside tabs
- 4) Finished floor should be brought up to edges of box on the 3" sides and within 1/4" of the threaded inner "ears" creating a "shelf" to accommodate the larger tabs on the adjusting ring

**\*\*\*IMPORTANT\*\*\* FINISHED FLOOR MUST COVER OUTSIDE TABS OF BOX BY AT LEAST 1/4"**

- 5) Drop adjusting ring into opening of finished floor and align inner "ears" (outside tabs should rest on finished flooring)
- 6) Mount provided receptacle to adapter plate. Add gasket. Drop into aligned adjusting ring.
- 7) Place outside gasket around entire assembly
- 8) Place brass plate on top of gasket, making sure all inner ears are aligned
- 9) Secure brass plate and adjusting ring to inner threaded ears of box using (6) 6/32 x 3/4" or 1-1/4" brass screws (all included)

### INSTALLATION INSTRUCTIONS ON FINISHED FLOORS

- 1) Use with LEW ELECTRIC SWB-6 Partitioned box only
- 2) Rough in for box should not exceed 6" X 3 1/2"
- 3) Use box as a template for routing by turning it over onto wood floor and tracing outside nailing tabs onto floor
- 4) Routing depth should be between 1/4" and 1/2"
- 5) Make sure inside "ears" are free of any flooring underneath to allow for brass assembly screw
- 6) Follow above steps 5 through 9

